
ALBUM EDIT LEVEL
INIT ALBUM EDIT
ALBUM EDIT SELECT
CONTROL DATA
SELECT ALBUM
SELECT THE ALBUM
342
MASKED INPUTS
INPUT REQUEST
ALBUM
CONTROL DATA
INPUT REQUEST
TEXT
MAGAZINE MEMORY
MASKED INPUTS
TYPE SELECT
343
SEQUENCE PICTURE SELECT
NEW SELECTION
SEQ DISK SEL
NEW SELECTION
SET TIME SEL
NEW SELECTION
SEQ PICTURES
344
MAGAZINE MEMORY
INPUT REQUEST
TEXT
MASKED INPUTS
SEQ DISKS
345
MAGAZINE MEMORY
INPUT REQUEST
TEXT
MASKED INPUTS
NEW SELECTION
SET VIEW TIME
346
MAGAZINE MEMORY
INPUT REQUEST
MASKED INPUTS
TEXT
CONTROL DATA

FIG. 10