
S1
LOADING FIRST ESTIMATE
FROM S20
S2
NORMALIZING CREATING $F_{OLD}(\bar{x})$
S3
LOADING OR GENERATING START $m(\bar{x})$
S4
LOADING PARAMETERS LOADING GRID POINTS
S5
PROVIDING REFERENCE DATA
TO S6
FROM S5
S6
LOADING DENS. DISTR. FROM S2
S7
LOADING PROJ. GEOMETRY DATA
S8
LOADING IND. PARAM. FOR EACH PROJECTION
S9
FIRST ITERATION
NO
YES
S10
CALC. SMEAR. FUNCT. & REF. DATA NOT FROM SAMPLE OBS.
S11
CALC. REF. DATA TO ELIM. STE.
S12
LOADING PSF, SMEAR. FUNC. & REF. DATA
S13
CALCULATE & CORRECT PROJECTIONS
TO S14

FIG. 2A

FIG. 2B