
301
RECEIVE PARAMETER SET FROM COMMUNICATION SYSTEM
MAINTENANCE MODE
302
Y
N
304
INHIBIT ALL USER CLASSES EXCEPT MAINTENANCE CLASSES
IS ANTENNA BEAM SCHEDULED FOR TURNOFF
306
Y
N
308
INHIBIT ALL USER CLASSES
MEASURE CURRENT DEMAND FOR SERVICES
309
ARE AVAILABLE TRAFFIC CHANNELS BELOW THRESHOLD LEVEL
310
Y
N
312
INHIBIT REGULAR SUBSCRIBER CLASSES
BROADCAST PARAMETER SET INCLUDING INHIBITED USER CLASSES
314
300

FIG. 9