
CURRENT FUNCTION
REFERENCE TEMPERATURE CALCULATION
HEAT FLUX CALCULATION
HEAT FLUX OUTPUT
SAMPLE TEMPERATURE CALCULATION
SAMPLE TEMPERATURE OUTPUT
SAMPLE CURRENT FUNCTION
11
12
13
14
15
16
17
18
32
33
34
35
36
37
38
39
40
41

FIG. 2