FIG.15


START
S63
ERROR ?
YES
NO
S66
IS THE ERROR IN ANY OF THE COPYING DISK DRIVES ?
NO
YES
S70
DISPLAY ERRORS
S67
ISOLATE THE COPYING DISK DRIVE HAVING AN ERROR FROM THE OPERATION
S68
TURN ON THE ERROR INDICATOR CORRESPONDING TO THE FAILING COPYING DISK DRIVE
S69
IS THERE ANY NORMAL COPYING DISK DRIVE ?
NO
YES
S64
HAS ALL DATA BEEN COPIED ?
NO
YES
END OF COPYING OPERATION
S65
END