
MOBILE TRANSMITS SIGNALING INFO.
BASE ACQUIRES/ INTERPRETS MOBILE TRANSMISSION
BASE PREPARES/ TRANSMITS POWER CONTROL BITS
MOBILE ACQUIRES/ INTERPRETS POWER CONTROL BITS AND ADJUSTS POWER ACCORDINGLY

FIG. 1