
FROM STEP 1202, FIG.12
1500
SELECT ZONE BOUNDARY POINT
1204
1502
DRAW LINE OF PREDETERMINED SLOPE THROUGH SELECTED ZONE BOUNDARY POINT
1504
DOES LINE INTERSECT BOUNDARY OF SELECTED REGION ?
NO
TO STEP 1202, FIG.12
YES
1700
DOES LINE INTERSECT BOUNDARY OF SELECTED REGION AT SELECTED ZONE BOUNDARY POINT ONLY ?
NO
TO STEP 1202, FIG.12
YES
1508
HAVE ALL ZONE BOUNDARY POINTS BEEN SELECTED ?
NO
YES
TO STEP 1206, FIG.12

FIG.17