
BASE STATION
101
CONSTANTLY BROADCAST PILOT SIGNAL
107
RECEIVE ORIGINATION MESSAGE. ASSIGN SSRC TIME SLOT TO MOBILE TERMINAL SEND SSRC ASSIGNMENT MESSAGE.
PILOT CHANNEL
ACCESS CHANNEL
PAGING CHANNEL
MOBILE TERMINAL
DETECT PACKET DATA CALL INITIATED BY USER.
SEND ORIGINATION MESSAGE SPECIFYING PACKET DATA CALL.
RECEIVE SSRC ASSIGNMENT MESSAGE. TUNE TO ASSIGNED SSRC, AND STORE SSRC AND TIME SLOT IDENTIFIERS.
103
105
109

FIG. 1