
MOBILE TERMINAL
BASE STATION
SET TRANSMITTER TO LOWEST POWER LEVEL.
201
SEND SYNCH-RONIZATION MESSAGE AT ASSIGNED TIME SLOT ON SSRC.
SSRC
203
207
SYNCHRONIZATION MESSAGE NOT UNDERSTOOD
START ACKNOWLEDGMENT TIMER.
205
ACKNOWLEDGMENT TIMER EXPIRES. RESEND SYNCH-RONIZATION MESSAGE AT NEXT POWER SETTING.
209
SSRC
RECEIVE SYNCHRONIZATION MESSAGE. SYNCHRONIZE TO MOBILE TERMINAL USING SYNCHRONIZATION MESSAGE IN PREAMBLE. ASSIGN TRAFFIC CHANNEL. SEND CHANNEL ASSIGNMENT MESSAGE.
211
213
RESPONSE RESERVATION CHANNEL
RECEIVE CHANNEL ASSIGNMENT MESSAGE.
TUNE TO ASSIGNED TRAFFIC CHANNEL.
SEND DATA FRAMES ON ASSIGNED TRAFFIC CHANNEL AT ASSIGNED SEND TIME.
RTC
215
RECEIVE DATA FRAMES USING A LAYER TWO ARQ PROTOCOL.

FIG.2